



ACE 600

Application note	No. 2
Scope:	Incorrect layer thickness
Version 1.2	21 May 2018

In case the deposited layer thickness obviously does not correspond with your process settings and/or final reading of the thickness monitor, please, double check the quartz position settings in the “settings” panel:





“Stage” means that you set the system for the quartz module physically mounted at the center of the stage.

“Side” means that you set the system for the quartz module mounted on a side arm (in case large samples need to be coated).

